

Throttle Opening (%)	Engine Revs (1/min)																						Throttle Opening (%)	
	500	1.000	1.500	2.000	2.500	3.000	3.500	4.000	4.500	5.000	5.500	6.000	6.500	7.000	7.500	8.000	8.500	9.000	9.500	10.000	10.500	11.000		11.500
0-15	PilotJet (Leerlauf-Benzin)																						0-15	
	Pilot Air Jet (Leerlauf-Luft) on											Pilot Air Solenoid Jet (Magnet) off												
16-20	Needle Jet (Nadeldüse-Benzin)																						16-20	
	Main Air Jet (Luftdüse)											PilotJet (Leerlauf-Benzin)												
21-25	Needle Jet (Nadeldüse-Benzin)																						21-25	
	Pilot Air Jet (Leerlauf-Luft) on											Pilot Air Solenoid Jet (Magnet) off												
26-30	Needle Jet (Nadeldüse-Benzin)																						26-30	
	Main Air Jet (Luftdüse)											permanentes Klicken												
31-35	Needle Jet (Nadeldüse-Benzin)																						31-35	
	Pilot Air Jet (Leerlauf-Luft) on											Main Air Solenoid Jet (Magnet) Main Air Solenoid Jet (Magnet) off												
36-40	Needle Jet (Nadeldüse-Benzin)																						36-40	
	Main Air Jet (Luftdüse)											permanentes Klicken												
41-45	Needle Jet (Nadeldüse-Benzin)																						41-45	
	Pilot Air Jet (Leerlauf-Luft) on											Main Air Solenoid Jet (Magnet) Main Air Solenoid Jet (Magnet) off												
46-50	Needle Jet (Nadeldüse-Benzin)																						46-50	
	Main Air Jet (Luftdüse)											permanentes Klicken												
51-55	Needle Jet (Nadeldüse-Benzin)																						51-55	
	Main Air Jet (Luftdüse)											on Main Air Solenoid Jet (Magnet) off												
56-60	Needle Jet (Nadeldüse-Benzin)																						56-60	
	Main Air Jet (Luftdüse)											Needle Jet (Nadeldüse-Benzin)												
61-65	Needle Jet (Nadeldüse-Benzin)																						61-65	
	Main Air Jet (Luftdüse)											Needle Jet (Nadeldüse-Benzin)												
66-70	Needle Jet (Nadeldüse-Benzin)																						66-70	
	Main Air Jet (Luftdüse)											Needle Jet (Nadeldüse-Benzin)												
71-75	Needle Jet (Nadeldüse-Benzin)																						71-75	
	Main Air Jet (Luftdüse)											Main Jet Powerjet (1)												
76-80	Needle Jet (Nadeldüse-Benzin)																						76-80	
	Main Air Jet (Luftdüse)											Main Jet Powerjet (1)												
81-85	Needle Jet (Nadeldüse-Benzin)																						81-85	
	Main Air Jet (Luftdüse)											Main Jet Powerjet (1)												
86-90	Needle Jet (Nadeldüse-Benzin)																						86-90	
	Main Air Jet (Luftdüse)											Main Jet Powerjet (1)												
91-95	Needle Jet (Nadeldüse-Benzin)																						91-95	
	Main Air Jet (Luftdüse)											Main Jet Powerjet (1)												
96-100	Needle Jet (Nadeldüse-Benzin)																						96-100	
	Main Air Jet (Luftdüse)											Main Jet Powerjet (1)												